Waterproof Mascara

AkzoNobel Surface Chemistry Global Personal Care

6238-62A



## Description DERMACRYL<sup>®</sup> 79 polymer provides water resistance, increased moisture protection, and rub-off resistance.

## Formula

Trade Name	INCI Name	% w/w	Supplier
Phase A			
Carnauba Wax	Carnauba (Copernicia Cerifera) Wax	1.00%	Rita
Candelilla Wax	Candelilla (Euphorbia Cerifera) Wax	5.00%	Rita
Beeswax	Beeswax	5.00%	Strahl & Pitsch
Ozokerite Wax	Ozokerite	2.00%	Strahl & Pitsch
Emersol 132	Stearic Acid T.P.	5.00%	Cognis
Cetyl Alcohol	Cetyl Alcohol	3.00%	
Fluilan	Lanolin Oil	3.00%	Croda
Phase B			
Deionized Water	Water (Aqua)	q.s.	
DERMACRYL 79 polymer	Acrylates/Octylacrylamide Copolymer	5.00%	AkzoNobel Global
			Personal Care
Propylene Glycol	Propylene Glycol	3.00%	
Ammonium Hydroxide 28%	Ammonium Hydroxide	2.75%	
Phase C			
7133 Purified Black Oxide	Iron Oxides	10.00%	Sensient
Phase D			
Germaben IIE	Propylene Glycol (and) Diazolidinyl Urea (and)	1.00%	Sutton Labs
	Methylparaben (and) Propylparaben		
	Total:	100.00%	
Procedure			

Procedure

Combine all the ingredients of Phase A and heat to 85°C. Combine all the ingredients of Phase B with the exception of the DERMACRYL 79 polymer. Begin agitation and slowly sift in the DERMACRYL 79 polymer and heat to 85°C. When each phase is uniform, add Phase A to Phase B. With constant agitation, add Phase C. At 50°C, add Phase D. Cool to room temperature.

## **Properties**

Viscosity:

pH:

```
7.3 – 8.3
Not Measured
```

All information concerning our products and/or all suggestions for handling and use contained herein (including formulation and toxicity information) are offered in good faith and are believed to be reliable. However Akzo Nobel Surface Chemistry makes no warranty express or implied (i) as to the accuracy or sufficiency of such information and/or suggestions, (ii) as to any product's merchantability or fitness for a particular use or (iii) that any suggested use (including use in any formulation) will not infringe any patent. Nothing contained herein shall be construed as granting or extending any license under any patent. The user must determine for itself by preliminary tests or otherwise the suitability of any product and of any information contained herein (including but not limited to formulation and toxicity information) for the user's purpose. The safety of any formulation schecibed herein has not been established. The suitability and safety of a formulation should be confirmed in all respects by the user prior to use. The information contained herein supersedes all previously issued bulletins on the subject matter covered.

Europe: Sempach-Station, Switzerland, T: +41 (0)41-469-69-66, F: +41 (0)41-469-69-06, e: personalcare.europe@akzonobel.com Americas: Bridgewater, New Jersey, U.S.A., T: 888 331-6212, F: 908-707-3664, e: personalcare.usa@akzonobel.com South America: Itupeva, SP, Brazil, T: 55-11-4591-8800, F: 55-11-4591-8804, e: personalcare.southamerica@akzonobel.com Asia/Pacific: Shanghai, P.R. China, Tel: +86-21-5774-5700, Fax: +86-21- 6774-2936, e-mail: personalcare.asia@akzonobel.com www.akzonobel.com/PersonalCare